

VALMEX® and POLYMAR®

1. No solvents or strong alkaline cleaners shall be used. Use of these products may cause damage. Our technical textiles can be cleaned with **alkali free detergents**.
2. Rinse off the soil on the surface with cold or warm water.
3. Apply the amount of cleaner required for the type of soiling, following the recommended concentration laid down by the manufacturer of the cleaner. Spray it on or wipe it on to the material with a cloth. Leave the cleaner to work for up to 5 minutes and wipe it off with a cloth.
4. Rinse off the dirt and cleaner with pure cold or warm water. Then dry off thoroughly with a dry cloth. Do not overheat the surface. **Do not let dry by air, it could lead to change of colour!** Please read recommendations of supplier attentively.
5. The material must be stocked clean and under absolute dry conditions.

If in doubt about a particular cleaning solution, please do not hesitate to contact us for our recommendation. Low & Bonar GmbH is prepared to carry out tests on the proposed detergents and check their recommendations.

This information is according to actual knowledge as per December 2013 and is without legal commitment.

Cleaning instructions